

How to replace the front hub bearing on Opel Astra H

Carry out replacement in the following order:

1

Tighten the parking brake lever.

2

Place wedge blocks under the rear wheels.

2 Loosen the wheel mounting bolts.

4

Raise the front of the car and secure on supports.

5

Remove the front wheels.

6 1



Unscrew the brake caliper fastening

www.autodoc.co.uk 1–9



How to replace the front hub bearing on Opel Astra H

6.2





Remove the brake caliper.

(i) AutoDoc recommends:

Tie the caliper to the suspension or to the body with a wire without disconnecting from the brake hose to prevent depressurization of the brake system.

Do not press the brake pedal after removing the brake pads. This will lead to the piston drop out of the brake cylinder, brake fluid leakage and the system depressurization.

Disconnect the ABS sensor.

8.2



8.3



www.autodoc.co.uk 2–9

How to replace the front hub bearing on Opel Astra H

9.1



Unscrew the brake disc mounting bolts and remove it.

9.2



10

Pry the hub cap with a screwdriver and remove it.

11




Unscrew the hub lock nut.

12



Unscrew the end fastening nut to the steering knuckle.

13.1



Using a special tool push the steering rod end out of the steering knuckle.

www.autodoc.co.uk 3–9

How to replace the front hub bearing on Opel Astra H







Unscrew the wheel hub fastening nut









Remove the hub and the bearing together, since they are a sealed unit.

www.autodoc.co.uk 4–9

How to replace the front hub bearing on Opel Astra H



Install the wheel hub on the steering knuckle.






Tighten the hub.







Connect the ABS sensor.

www.autodoc.co.uk 5–9

How to replace the front hub bearing on Opel Astra H

18.2





19



Screw the wheel hub lock nut.

20.1



Install the hub bearing protection cap.


www.autodoc.co.uk 6–9



20.2



21.1



Connect the tie rod end to the steering knuckle and tighten it.

212



22



Install the brake disc.

23



Tighten the brake disc fastening

241



Install the brake caliper and fix it.

www.autodoc.co.uk 7–9





Install the wheel.

Lower the car and working in a cross order, tighten the wheel bolts.



We hope that this information have been useful for you!



Video tutorials

Watch our detailed video guides about your Opel Astra H repair on our youtube channel. Watch video guides.



AutoDoc online

Highest quality wheel/hub bearing kits for your car Opel Astra H are available on AutoDoc. Go to the website.



How to replace the front hub bearing on Opel Astra H

AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE













i Disclaimer:

The document contains only general recommendations that may be useful for you when you perform repair or replacement works. AutoDoc shall not be liable for any loss, injury, damage of property, acquired in the repair or replacement process due to incorrect usage or misinterpretation of the provided information.

AutoDoc shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for informative purposes only and cannot replace advice from specialists.

AutoDoc shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AutoDoc strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

AUTODOC IN SOCIAL MEDIA













www.autodoc.co.uk